



Mouse Driver Installation Manual

Version 1.1

Revision	Date	Comments	Name
1.1	06.08.2018	Added Windows 10 to supported operating systems.	C. Köpp
1.0	30.06.2010	Modifications for the certified version of the driver.	C. Köpp
0.1	28.05.2010	Initial Version.	C. Köpp

Introduction

This manual guides you through the Mouse Driver installation. There are two ways to install the driver: Using the installation wizard or using the command shell for an unattended install. During the installation it doesn't matter whether the MDM-Mouse device is already connected or not.

Supported Operating Systems

Windows XP	32-bit (x86) / 64-bit (x64)
Windows Vista	32-bit (x86) / 64-bit (x64)
Windows 7	32-bit (x86) / 64-bit (x64)
Windows 10	64-bit (x64)

Preparation *(only required if the old driver Version 1.0.0.0 is installed)*

1. From the Windows Start Menu select the MDM-Driver entry and execute the Uninstall program. Please follow the instructions of the wizard.

Installation via Installation Wizard

1. To install the mouse driver double click one of the following software installer. For 32-bit OS use MdmMouseSetup32.msi and for 64-bit OS use MdmMouseSetup64.msi.
2. Follow the instructions of the installer. After the installation please close the wizard.

Unattended Installation

From a command shell you can use the msixec tool to install the driver without a GUI.

1. For 32-bit OS use MdmMouseSetup32.msi and for 64-bit OS use MdmMouseSetup64.msi
2. Open a command shell (DOS-Box) and type: msixec /quite /i <location of the driver/file name>, e.g. msixec /quiet /i [c:\MdmMouseSetup64.msi](#).

Uninstalling the driver

If necessary the driver can be uninstalled easily. Simply restart the Installation Wizard and choose the Remove MDM-Mouse option and click the Finish-Button. Alternatively, you can use the „Add or Remove Programs-Application“ in the Control Panel.